




WEEE

RECYCLING
end of life instructions

BATTERY



This **WEEE** and **BATTERY** symbol, affixed to this product indicates it should not be processed with general waste. Join our commitment to a sustainable future by dismantling your **Absolut Tabasco Glorifier** and recycling once at 'end of life' - then send to the electrical and electronic waste centre.



SEPERATING FOR RECYCLNG INSTRUCTIONS

Metal: choose metal recycling bin

LEDs, PCB, Battery, Plug/Adapter/Charger: choose Waste Electrical and Electronic Equipment (WEEE & BATTERY) recycling bins

Cardboard Packaging: use the cardboard paper recycling bin

Plastics: rPMMA choose plastics recycling bin, avoid general waste where possible.


User Guide

Essential to read before using this product



ABSOLUT TABASCO GLORIFIER



FRONT/SIDE VIEW



BIRDS EYE VIEW



MEASUREMENTS

Accessories Provided

Multi Country 5v, 2A charging adapter plug, with 2.1mm connector



Materials - Maintenance - Warnings – Troubleshooting

Electronics/Compliance/Recall

PCB with 110pcs x LEDs type 2835. 5v, 2A 10W 'Multi Country' plug-in charger.
Lithium-ion Polymer Battery 3.7V, 3,000mAh. For further info: compliance, recycling or recalls contact hello@illumX.com

Maintenance

Wipe with a warm damp cloth, no chemicals. Regularly check connectors for damage. If not permanently in use, keep packaging and store **Absolut Tabasco Glorifier** in a clean and dry environment.

Warnings

Do not modify, disassemble, open, drop, crush, puncture, shred and/or replace any of the accessories and/or parts or warranty is invalid. **DANGER!** Never handle electrical items with wet hands. Do not use excessive force when inserting/removing connectors. This is a fragile item, always handle with care. Any misuse can cause accidents and/or injuries. Do not leave on charge permanently, disconnect between charges. Adding Sparklers is done at your own risk, we will accept not responsibility or liability for adding any form of pyrotechnics to this product. This is not a toy – **keep away from children.**

Troubleshooting

Glorifier is not lit

- ensure charger is pushed in completely and red charging indicator is on.
- check for visible damage to power adapter or connections.

Flickering

- remove charger, drain power until light is off, then recharge again.

Overheating

- if Glorifier is too hot, or smells bad, unplug and allow to cool.
- check the Glorifier is not blocked or has restricted airflow.

Broken - if out of warranty, seek professional advice, or refer to **recycling section.**

Legal German Information only

Das Symbol des durchgestrichenen Mülleimers besagt, dass dieses Elektro- bzw. Elektronikgerät am Ende seiner Lebensdauer nicht im Hausmüll entsorgt werden darf, sondern vom Endnutzer einer getrennten Sammlung zugeführt werden muss. Zur Rückgabe stehen in Ihrer Nähe kostenfreie Sammelstellen für Elektroaltgeräte sowie ggf. weitere Annahmestellen für die Wiederverwendung der Geräte zur Verfügung. Die Adressen können Sie von Ihrer Stadt- bzw. Kommunalverwaltung erhalten. Auch Vertreiber mit einer Verkaufsfläche für Elektro- und Elektronikgeräte von mindestens 400 Quadratmetern sowie Vertreiber von Lebensmitteln mit einer Gesamtverkaufsfläche von mindestens 800 Quadratmetern, die mehrmals im Kalenderjahr oder dauerhaft Elektro- und Elektronikgeräte anbieten und auf dem Markt bereitstellen, sind verpflichtet unentgeltlich alte Elektro- und Elektronikgeräte zurückzunehmen. Diese müssen bei der Abgabe eines neuen Elektro- oder Elektronikgerätes an einen Endnutzer ein Altgerät des Endnutzers der gleichen Geräteart, das im Wesentlichen die gleichen Funktionen wie das neue Gerät erfüllt, am Ort der Abgabe oder in unmittelbarer Nähe hierzu unentgeltlich zurückzunehmen sowie ohne Kauf eines Elektro- oder Elektronikgerätes auf Verlangen des Endnutzers bis zu drei Altgeräte pro Geräteart, die in keiner äußeren Abmessung größer als 25 Zentimeter sind, im Einzelhandelsgeschäft oder in unmittelbarer Nähe hierzu unentgeltlich zurückzunehmen. Bei einem Vertrieb unter Verwendung von Fernkommunikationsmitteln gelten als Verkaufsflächen des Vertreibers alle Lager- und Versandflächen. Sofern das alte Elektro- bzw. Elektronikgerät personenbezogene Daten enthält, sind Sie selbst für deren Löschung verantwortlich, bevor Sie es zurückgeben. Sofern dies ohne Zerstörung des alten Elektro- oder Elektronikgerätes möglich ist, entnehmen Sie diesem bitte alte Batterien oder Akkus sowie Altlampen, bevor Sie es zur Entsorgung zurückgeben, und führen diese einer separaten Sammlung zu. Weitere Informationen zum Elektrogesetz finden Sie auf www.elektrogesetz.de

Set Up Guide

Carefully remove your **Absolut Tabasco Glorifier** and **accessories** from the packaging. Try to reuse our packaging or keep for future storage. If disposing, see **Recycling Section.**

Charging

- Choose your country plug and install on the charger.
- Gently push the 2.1mm connector on the end of the 5V charging adapter into the back of your **Absolut Tabasco Glorifier**.
- Find an available AC Wall Socket.
- Plug-in the 5V UK charger.
- Red LED located on the 5V charger indicates 'charging in progress'
- Green LED located on the 5V charger indicates 'fully charged'
- Charging time: around 2 hours.
- Charge life-cycle: around 7 hours. Note...Lithium-ion Polymer Batteries deteriorate over time, expect a shorter life-cycle as your **Glorifier** ages.
- Ensure you disconnect once fully charged and void leaving on-charge permanently.

Displaying and Table Serving

