



WEEE

RECYCLING


end of life instructions



BATTERY

The **WEEE** and **BATTERY** symbols affixed to the electronics indicate they should not be processed with general waste. Join our commitment to a sustainable future by dismantling your **Ciroc Small LED Ice Bucket** and recycling once at 'end of life' - then send the parts to a recycling centre.

Disassemble Use a Pozi-Pan head screwdriver and wire cutters to disassemble.



SEPERATING FOR RECYCLING

1. Metal Recycling Bin

Screws and washers.

2. WEEE Electronics Recycling Bin

PCB Board, Switches, LEDs, charging adapter.

3. Battery Recycling Bin: Li-ion Battery

Plastic Recycling Bin (avoid general waste) PS Bucket, PS plastic handles ABS electronics plastics, ABS drainer.

4. Cardboard Recycling Bin:

All packaging products.

USER MANUAL


CIROC SMALL LED ICE BUCKET




ACCESSORIES PROVIDED

1. Drainer
2. LED Puck
3. Euro charging adapter plug + USB cable

1.



2.



3.



Materials - Maintenance - Warnings – Troubleshooting

Electronics/Compliance/Recall

PCB with 24pcs x LEDs type 2835. 5v, 1A, 5W 'EURO plug-in USB charger. Lithium-ion Polymer Battery 3.7V, 1,500mAh. For further info: compliance, recycling or recalls contact hello@illumX.com

Maintenance

Wipe with a warm damp cloth, no chemicals. Rinse to clean, **not dishwasher safe**. Regularly check connectors for damage. If not permanently in use, keep packaging and store your Ice Bucket in a clean and dry environment.

Warnings

Do not modify, disassemble, open, drop, crush, puncture, shred and/or replace any of the accessories and/or parts or warranty is invalid. Do not use excessive force when inserting/removing connectors. This is a fragile item, always handle with care. Any misuse can cause accidents and/or injuries. Do not leave on charge permanently, disconnect between charges. This is not a toy – **keep away from children**.

Troubleshooting

Ice Bucket Electronics is not lit

- ensure charger is magnetically connected to LED Puck and red charging indicator is on and wait for 2 hours.
- check for visible damage to power adapter or connections.

Flickering

- remove charger, drain power until light is off, then recharge again.

Overheating


- if LED PUCK is too hot, or smells bad, turn off/disconnect charger and allow to cool.

Broken - if out of warranty, seek professional advice, or refer to **recycling section**.

SET UP AND CHARGING GUIDE

Charging

- Remove the Euro charging adapter/plug from it's packaging.
- Find an available AC Wall Socket or USB connecting socket.
- Notice the 2-prong connector on the end of the Euro charging adapter/plug. This is a magnetic charging connector.
- Find the 2-prong connector/receiver underneath the **LED PUCK**. This is also magnetic. Magnetically connect together.
- Connect to available AC Wall socket or USB connecting socket.



Use supplied Charger Plug or use USB an available Charging Socket

- Red LED on **LED PUCK** indicates 'charging in progress'.
- Green LED on **LED PUCK** indicates 'fully charged'.
- Charging time: around 2 hours.
- Charge life-cycle: around 5 hours. Note...Lithium-ion Polymer Batteries deteriorate over time, expect a shorter life-cycle as your **LED PUCK** ages.
- Ensure you disconnect once fully charged and avoid leaving on-charge permanently.

Preparing your CIROC SMALL LED ICE BUCKET for use

