



WEEE

RECYCLING

end of life instructions

BATTERY




The **WEEE** and **BATTERY** symbol, affixed to this product indicates it should not be processed with general waste. Join our commitment to a sustainable future by dismantling your **CHIVAS GLORIFIER** and recycling once at 'end of life' - then send to the electrical and electronic waste centre.

DISMANTLING INSTRUCTIONS

a. Use a Pozi-Pan screwdriver to disassemble this unit.

b. Separate the parts as shown.

c. Send to a recycling centre, ensuring the parts are placed in the correct recycling bins, see below directions.



RECYCLING CENTRE – ADVICE/DIRECTIONS

Plastic Recycling Bin (avoid general waste where possible): rABS main structure, screw covers, cover caps, rPMMA tube & rubber feet.

Metal Recycling Bin: Bottle neck holder, base/holder, screws, washers & plunger.

WEEE Recycling Bin LEDs, PCB, switches, plug-in charger.

WEEE Battery Recycling Bin: Polymer Lithium-ion rechargeable battery cell.


Glass Recycling Bin: Soda-Lime glass ctystal shapes

Cardboard & Paper Recycling Bin: Cardboard Carton & inner packaging paper.

USER MANUAL

CHIVAS GLORIFIER 2025, 1/pc Code: CR8296

Bottle not included



CHIVAS GLORIFIER - CONTENTS OF THE CARTON

3. Bottle Ring



1. Glorifier Base




2. Luckenbooth



4. Multi-Country Charger



5. Spare Cap Cover



Materials - Maintenance - Warnings – Troubleshooting

Electronics/Compliance/Recall

PCB with 30pcs x LEDs type 2835. 5v, 2A 10W 'Multi Country' plug-in charger.
Lithium-ion Polymer Battery 3.7V, 3,000mAh. For further info: compliance, recycling or recalls contact hello@illumX.com, address to Compliance Manager

Maintenance - Wipe with a warm damp cloth, no chemicals.

Warnings

Do not modify, disassemble, open, drop, crush, puncture, shred and/or replace any of the accessories and/or parts or warranty is invalid. **DANGER!** Never handle electrical items with wet hands. Do not use excessive force when inserting/removing connectors. This is a fragile item, always handle with care. Any misuse can cause accidents and/or injuries. Do not leave on charge permanently, disconnect between charges. Adding Sparklers is done at your own risk, we will accept not responsibility or liability for adding any form of pyrotechnics to this product. This is not a toy – **keep away from children.**

Troubleshooting

Glorifier is not lit

- ensure charger is pushed in completely and red charging indicator is on.
- check for visible damage to power adapter or connectors.

Flickering

- remove charger, drain power until light is off, then recharge again.

Overheating

- if Glorifier is too hot, or smells bad, unplug and allow to cool.
- check the Glorifier is not blocked or has restricted airflow.

Broken - if out of warranty, seek professional advice, or refer to **recycling section.**

Legal German Information only

Das Symbol des durchgestrichenen Mülleimers besagt, dass dieses Elektro- bzw. Elektronikgerät am Ende seiner Lebensdauer nicht im Hausmüll entsorgt werden darf, sondern vom Endnutzer einer getrennten Sammlung zugeführt werden muss. Zur Rückgabe stehen in Ihrer Nähe kostenfreie Sammelstellen für Elektroaltgeräte sowie ggf. weitere Annahmestellen für die Wiederverwendung der Geräte zur Verfügung. Die Adressen können Sie von Ihrer Stadt- bzw. Kommunalverwaltung erhalten. Auch Vertreiber mit einer Verkaufsfläche für Elektro- und Elektronikgeräte von mindestens 400 Quadratmetern sowie Vertreiber von Lebensmitteln mit einer Gesamtverkaufsfläche von mindestens 800 Quadratmetern, die mehrmals im Kalenderjahr oder dauerhaft Elektro- und Elektronikgeräte anbieten und auf dem Markt bereitstellen, sind verpflichtet unentgeltlich alte Elektro- und Elektronikgeräte zurückzunehmen. Diese müssen bei der Abgabe eines neuen Elektro- oder Elektronikgerätes an einen Endnutzer ein Altgerät des Endnutzers der gleichen Geräteart, das im Wesentlichen die gleichen Funktionen wie das neue Gerät erfüllt, am Ort der Abgabe oder in unmittelbarer Nähe hierzu unentgeltlich zurückzunehmen sowie ohne Kauf eines Elektro- oder Elektronikgerätes auf Verlangen des Endnutzers bis zu drei Altgeräte pro Geräteart, die in keiner äußeren Abmessung größer als 25 Zentimeter sind, im Einzelhandelsgeschäft oder in unmittelbarer Nähe hierzu unentgeltlich zurückzunehmen. Bei einem Vertrieb unter Verwendung von Fernkommunikationsmitteln gelten als Verkaufsflächen des Vertreibers alle Lager- und Versandflächen. Sofern das alte Elektro- bzw. Elektronikgerät personenbezogene Daten enthält, sind Sie selbst für deren Löschung verantwortlich, bevor Sie es zurückgeben. Sofern dies ohne Zerstörung des alten Elektro- oder Elektronikgerätes möglich ist, entnehmen Sie diesem bitte alle Batterien oder Akkus sowie Altlampen, bevor sie es zur Entsorgung zurückgeben, und führen diese einer separaten Sammlung zu. Weitere Informationen zum Elektrogesetz finden Sie auf www.elektrogesetz.de

Legal US Information only

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. *Please note that changes or modifications of this product is not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.* For Class B digital equipment or peripheral, the following statement or similar should be placed on a prominent position of the specification text of the User Manual.

SET UP GUIDE

Carefully remove the **CHIVAS GLORIFIER** contents from the packaging. Try to reuse our packaging or keep for future storage. If disposing, see **Recycling Section.**

CHOOSE YOUR CHIVAS GLORIFIER SET UP

Option 1

CHIVAS GLORIFIER
1. Glorifier Base only



Usage
Back Bar Glorifier

Option 2

CHIVAS GLORIFIER
Add **2. Luckenbooth & 3. Bottle Ring** to secure bottle for carrying




Usage
Back Bar Glorifier
or
Table Service Presenter

Option 2

Setup instructions
Choose any Chivas product from 70cl to 100cl

2. Screw in bottle holder

1. Remove cap



3. Pull plunger to raise & secure chosen bottle



4. Secure bottle before serving to table



ensure plunger is locked

CHARGING

- Choose your country plug and install onto the **4. Multi-Country Charger.**
- Gently push the 2.1mm connector into the back of the **3. Glorifier Base.**
- Find an available AC Wall Socket. Plug-in the 5V **4. Multi-Country Charger.**
- Red LED located on the 5V charger indicates 'charging in progress'
- Green LED located on the 5V charger indicates 'fully charged'
- Charging time: around 2 hours. Charge life-cycle: around 7 hours.
Note...Lithium-ion Polymer Batteries deteriorate over time, expect a shorter life-cycle as your **CHIVAS GLORIFIER** ages.
- Ensure you disconnect once fully charged - avoid leaving on-charge.